

# TYP M/E

**D** Montageanleitung  
**GB** Assembly Instructions  
**F** Instructions de montage  
**I** Istruzioni di montaggio  
**E** Instrucciones de montaje  
**H** Szerelési utasítás  
**NL** Montageaanwijzing  
 © Copyright by ZR 01/00 852 060

**Do it your self**

~1m  
 ø 8  
 TEFLON  
 mm

L  
 H  
 x1  
 x3  
 x1  
 x3  
 x1  
 x3  
 x1

**A..**

L-30  
 min. 150  
 $X = 75 \pm 5$

**A1**

**A2**

TEFLON

**A3**

min. 28  
 75 75  
 1 2 3 4 5 6

**A4**

75 L1 75  
 H-161  
 H

**A5**

$L_1 = L - 150$   
 $H_2 = H - 161$   
 60 60  
 $H_1 = h_1 + 86$

**A4**

H-161  
 75 75 L1 75  
 H

**A5**

H-78 + h<sub>1</sub>  
 60 60  
 $L_1 = L - 150$   
 h<sub>1</sub>

**A6**

**A7**

**A8**

**A7**

**A8**

**A9**

L  
 H  
 x1  
 x3  
 x1  
 x3  
 x1  
 x3  
 x1

**B..**

70  
 L-30  
 min. 150  
 $X = 75 \pm 5$

**B1**

**B2**

TEFLON

**B5**

$L_1 = L - 150$   
 $H_2 = H - 161$   
 60 60  
 $H_1 = h_1 + 86$   
 $L_2 = \frac{L}{2} - 85$

**B6**

**B7**

**B8**

**B9**

